



M. C. DIY Guide: Pool / Pond Connector

Option A



When the water is enough ⇒ screw ON Cap ⇒ Then the Rainwater will be stop supply and back to the downpipe.



† Use a nail for fast / remove the 50mm Ø Pipe

Option B